

▼ To connect the IPR:

1. Using the provided RCA cable, connect the IPR video out to a TV monitor using the yellow video connector.
2. Using the provided RCA cable, connect the IPR audio out to a TV monitor using the corresponding red and white audio connectors.
3. Using *customer-provided* cables, connect the IP Receiver to your Ethernet network, using the **LAN** port.
4. Connect a USB keyboard and mouse to the USB ports and install two AA batteries in the remote control.
5. Connect the IPR power cord to a powerstrip and power on the IPR using the triangular **Power** button on the front panel.



**Figure 3.** WM IPR – Rear Panel

Composite	Composite video out.
S-Video	Connect to standard TV.
Audio Out	Audio out left and right.
LAN	Connect to local area network.
USB Ports (2)	Connect USB mouse and/or keyboard.
VGA	Connect to a standard TV or a projector with a VGA port.
Power Plug	Connects to power cord.



**Figure 4.** WM IPR – Front Panel

Connected	Yellow. Blinks when you press any button on remote control.
Standby	Orange. Press Power button to toggle Standby on or off.
Recording	Red. Steady red when a recording is in progress.
Power	Green. Steady green when power is applied.

